

WING ATTACHED TO FUSELAGE WITH
RUBBER BANDS OVER TOP OF WING

JOIN SECTIONS 0—0

0

RUDDER

2 TIGHT FITTING CLOTHING SNAPS


0

.064" WIRE

$\frac{1}{16} \times \frac{1}{16}$

$5\frac{1}{2}$

1° NEGATIVE SETTING



REAR FUSELAGE