


R1 MAKE 3 EA. 1/16" HARD Balsa.
1. MAINWING POSTERIOR
HOLLOW MIDDLE PLY AS REQUIRED FOR
CONTROL CABLE. SECURE CABLE WITH
EPOXY. FEED CONTROL WIRE THRU SHEATH
AT ASSEMBLY



LIGHTENING HOLES APPROX. AS SHOWN

