



3/8" GOOD BALSA SPARS
1/16" WEBS AFT OF SPARS
1/16" SHEETING
USE WICK HINGES
SOLID BALSA WING TIPS
ROUTE THROTTLE NYRDS AFTER NECELLE INST.
DIHEDRAL SET AT 2 deg. OUTER WINGS
USE 1/8 PLY DIHEDRAL BRACES FOR & AFT

WARNING ----- MAKE SURE THE GAP IN THE NACELLE IS EXACTLY (2 9/16")
make up wing in three sections
install nyrods for throtle before sheeting top center section

WTF 225 Twin Sport by Fort Worth R/C
DESIGNED MARCH 1995

